




USER MANUAL – EN

IN 7152 Power Rack inSPORTline Cable Column CC300



CONTENTS

IMPORTANT SAFETY PRECAUTIONS	3
PARAMETERS.....	3
PARTS LIST	4
HARDWARE LIST	5
ASSEMBLY	6
USAGE	14
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	15

IMPORTANT SAFETY PRECAUTIONS

Read the entire manual before using this equipment for the first time.

- Before starting the assembly, remove all the components from the box and make sure all listed parts were supplied.
- Retain the manual and the packaging for future use.
- Regularly check that the screws are tightened properly, otherwise you risk sustaining an injury.
- The product is not designed for outdoor use and must be placed on a flat and hard surface. It is recommended to place it on a mat, to protect your floor or carpet.
- Maintain a free area of at least 0.6 m around the equipment.
- The nuts have an anti-slip nylon circle, please tighten them with a wrench.
- The equipment is suitable for home use only.
- Do not try to modify the equipment in any way.
- Store the equipment in a dry place. Do not store it near water, in high temperatures or in direct sunlight.
- Clean the equipment with a detergent, clean water and a cloth (do not use gas, dilution or any other chemicals).
- Wear comfortable sports shoes and appropriate clothing. Do not exercise with bare feet, open shoes or socks.
- Always check your equipment before using it to make sure all parts are in working order.
- Incorrect or excessive exercising may damage your health.
- No adjustable part of the equipment should protrude and limit the user's movement.
- Do not leave children unsupervised near the equipment.
- Do not put your hands near any moving parts of the equipment while exercising.





























NOTE: Don't tighten the nuts and bolts with a tool until the assembly is complete.












WARNING: Before starting any exercise program, consult your physician, especially if you are over 35 years old or suffer from any health problems. The manufacturer is not liable for any injuries that may occur while exercising with this equipment. It is the owner's responsibility to ensure all other users familiarize themselves with the instructions in this manual.

PARAMETERS












Dimensions after assembly	Width: 180 cm x length: 150 cm x height: 213 cm
Weight	83 kg
Weight limit	200 kg
Category	H – home use only

PARTS LIST

<p>A</p>  <p>1 pc</p>	<p>B</p>  <p>1 pc</p>	<p>C</p>  <p>1 pc</p>	<p>D</p>  <p>1 pc</p>
<p>E</p>  <p>1 pc</p>	<p>F</p>  <p>1 pc</p>	<p>G</p>  <p>1 pc</p>	<p>H</p>  <p>1 pc</p>
<p>I</p>  <p>1 pc</p>	<p>J</p>  <p>1 pc</p>	<p>K</p>  <p>1 pc</p>	<p>L</p>  <p>1 pc</p>
<p>M</p>  <p>1 pc</p>	<p>N</p>  <p>1 pc</p>	<p>O</p>  <p>4 pcs</p>	<p>P</p>  <p>1 pc</p>
<p>Q</p>  <p>1 pc</p>	<p>R</p>  <p>1 pc</p>	<p>S</p>  <p>2 pcs</p>	<p>T</p>  <p>1 pc</p>
<p>U</p>  <p>1 pc</p>	<p>V</p>  <p>2 pcs</p>	<p>W</p>  <p>2 pc</p>	<p>X</p>  <p>21 pcs</p>
<p>Y</p>  <p>4 pcs</p>	<p>Z</p>  <p>2 pcs</p>	<p>IA</p>  <p>1 pc</p>	<p>IB</p>  <p>2 pcs</p>



<p>IC</p>  <p>2 pcs</p>	<p>ID</p>  <p>2 pcs</p>	<p>IE</p>  <p>7 pcs</p>	<p>IF</p>  <p>3 pcs</p>
<p>IG</p>  <p>4 pcs</p>	<p>IH</p>  <p>Cable A 9470 mm 1 pc</p>	<p>II</p>  <p>Cable B 4040 mm 1 pc</p>	<p>IJ</p>  <p>Cable C 4800 mm 1 pc</p>
<p>IK</p>  <p>2 pcs</p>	<p>IL</p>  <p>1 pc</p>	<p>IN</p>  <p>2 pcs</p>	

HARDWARE LIST

<p>1. M10*85 bolt + washers + nut</p>  <p>10 pcs</p>	<p>2. M12 nut + washer</p>  <p>4 pcs</p>	<p>3. M12*90 bolt + washers + nut</p>  <p>4 pcs</p>	<p>4. M10*25 bolt + washer</p>  <p>2 pcs</p>
<p>5. M12*100 bolt + washers + nut</p>  <p>2 pcs</p>	<p>6. M10*65 bolt + washers + nut</p>  <p>4 pcs</p>	<p>7. M10*45 bolt + washers + nut</p>  <p>19 pcs</p>	<p>8. M12*80 bolt + washers + nut</p>  <p>4 pcs</p>
<p>9. M10*35 bolt + washers + nut</p>  <p>2 pcs</p>	<p>10. M6*16 bolt + washer</p>  <p>6 pcs</p>	<p>11</p>  <p>1 pc</p>	



ASSEMBLY

STEP 1




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 2




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 3




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 4




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 5




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 6





The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 7




The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 8



The nuts have an anti-slip nylon circle, please tighten them with a wrench.

STEP 9



The nuts have an anti-slip nylon circle, please tighten them with a wrench.

USAGE

The power rack offers more than 100 various ways to effectively exercise your entire body. As usual, you can use a pulley to strengthen your arms, especially your biceps and triceps. You can also exercise your legs, especially the outer and inner thighs, by pulling them apart and pushing them together. There is also the option of the classic butterfly exercise to tone your chest muscles. The rack also has a lower pulley to simulate rowing and a multifunctional crossbar to practice pull-ups. Other useful features include flexible steel cables, nylon pulleys and holders for 30 mm diameter discs that can support up to 200 kg. There are 18 adjustable heights for grips so that users of any height can use this rack effectively.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

SK

INSPORTLIN s.r.o.

Headquarters, Warranty & Service centre:	Elektricka 6471, 911 01 Trenčin, Slovakia
CRN: 36311723	
VAT ID: SK2020177082	
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk
Web:	www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: