



## USER MANUAL – EN

### IN 22268 Hammock inSPORTline Simisus LG3400

#### SAFETY INSTRUCTIONS

- Please read these instructions thoroughly before using your hammock and keep it for future reference.
- Store in a cool, dry place when not in use.
- This is NOT a swing. Children using this product must be supervised at all times.
- Do not use if the product has any faulty part, including the strings, fabric or hammock eye.
- Please check your hammock safe capacity each and every time prior to using. Do not use it more than the recommended safe capacity.
- Do NOT leave your hammock outdoors in the rain or expose it to direct sunlight. The fabric will deteriorate and the colours may run (not all our hammocks are colour-fast, contact us to confirm).
- Check the area under the hammock for sharp objects, stones or other dirt that could pose a danger in case of falling.
- Do not jump or swing aggressively in a hammock.
- Always follow the provided instruction.
- Always test the hammock before putting your full weight in it.
- Do not modify. Subsequent modifications will void the warranty.
- Prevent any misuse! Risk of hanging and suffocation. Always remove the product when not in use. A hammock is no toy, sports or climbing device. Risk of injury due to falling or material damage.
- Weight limit: 120 kg

#### CARE

##### STORAGE

- Keep your hammock indoors when not in use and store in a cool, dry place.
- Direct sunlight and rain will deteriorate and reduce the lifespan of your hammock in time and the colours may run or change. Salt spray from the sea will also damage your hammock, so it is important to rinse your hammock regularly.

##### FOLDING

- Tie a loose knot in the end of strings as seen in the figure below to prevent tangles.



- Take the edge of the fabric at the middle of the hammock and fold in half, and then half again.



- Roll-up your hammock starting with the end strings.

## WASHING

- Tie a loose single knot in the end of strings at each end like the figure below.






- Machine-wash in a regular cycle and spin with cold water and non-bleach detergent, separated from your laundry.
- Remove hammock immediately after the spin cycle as dyes in the fabric may bleed if the hammock is not colour-fast.
- Do NOT use a dryer. Hang your hammock out to dry.




## WHERE TO HANG YOUR HAMMOCK

	<p>You will need to find two fixed points from which to hang your hammock. Try trees, beams or posts on your veranda. <b>Never hang your hammock from a free standing brick wall.</b> Your hammock will hang in any space of 2.5 to 3 meters or greater (2.7m for a single) this should leave the centre of the hammock about 20-30cm off the ground when you sit in it. (see Fig. 1)</p>
	<p>Often the distance will be greater and you will need some rope. It is important to attach one or both ends to a higher point to give the hammock some shape, roughly 90cm higher for each extra metre of span (see Fig. 2).</p>
	<p>Stretching the hammock flat like Fig. 3 is not comfortable and may cause it to break. The easiest way to determine where to hang your hammock is by holding the hammock in place before you attach any fixings.</p>

## HOW TO HANG YOUR HAMMOCK

 <p>Fig. 4</p>	<p><b>TREES</b></p> <p>Using a single rope (10mm polypropylene), tie a bowline (loop knot) in one end and pass it around the tree. Take the other end through the loop and tighten around the tree. You'll find that by rotating the rope around the tree it will tighten when you pull on the free end as in Fig. 4.</p> <p>Use this method for branches, beams or posts. With a smooth post you'll need to pass the rope around twice or more before taking the free end through the loop.</p>
 <p>Fig. 5 Using 8mm screw eye &amp; 8mm "S" hook</p>	<p><b>POSTS AND BEAMS</b></p> <p>You can fix a large screw eye into a post or beam. The screw eye can be attached directly to your hammock with an S hook (Fig. 5) or using a length of rope. Never attach to brick or concrete pillars unless you are certain they are safe.</p>
 <p>Fig. 6</p>	<p><b>MASONRY WALLS</b></p> <p>For sturdy masonry walls (not free standing ones like garden walls nor single brick, air brick or besser blocks), use a 10mm dyna bolt (Fig. 6) with a large washer at the end from which you can attach a rope.</p>


## ATTACHING YOUR HAMMOCK

<p><b>ON HOLIDAYS</b></p> <p>Direct to rope – Use the knot in Fig. 7, it's quick and easy to undo. Remove the metal eye inserts (if applicable) and keep in a safe place as they will tend to get twisted out by the knot.</p>	 <p>Fig. 7</p>
<p><b>AT HOME</b></p> <p>If using rope we recommend securely tying an S hook at the appropriate point (Fig. 8) to allow the hammock to be removed easily. If using a fixed hook or screw eye and S hooks just hook the eye straight on (Fig. 5 in previous section). You can also use our accessories recommended above.</p> <p>NOTE – If you are using a long piece of rope and find the end of the hammock is twisting too much when you use it then use a doubled piece of rope to solve this problem. (Fig. 9)</p>	 <p>Fig. 8</p> <p>Fig. 9</p>
<p><b>METAL EYE INSERTS (some hammocks only)</b></p> <p>These are not essential so don't worry if your hammock style doesn't have them – they are designed to be removable. The eye of the hammock will stretch with use and the metal insert may become too loose.</p> <p>There are two solutions:</p> <p>1) Tie some string around the base of the eye a couple of times and secure a knot (Fig. 10).</p>	 <p>Fig. 10</p>

2) Undo the last knot securing the base of the eye and take out a few turns of the binding and re-tie tightly. Don't trim the loose end until you are sure you have got it right.


### TANGLING

The end strings of your hammock can get a little tangled when not in use. Before hanging check for tangles by taking the eye in one hand and the corner of the fabric in the other and spread the end strings out. They should fan out evenly – if not you'll see something similar to Fig. 11 or 12. Pass the eye through the end strings as shown by the arrow until the end strings spread evenly. Repeat for the other end of your hammock.



## SAFETY INSTRUCTIONS

1. To avoid falling from a hammock, care should be taken when getting on to it. Firstly, sit in the middle of the hammock, facing out. Then twist the body until on to the hammock. **NEVER JUMP DIRECTLY ON TO THE HAMMOCK.**
2. When on the hammock, lie in the centre and do not lean towards one side as it may result in a fall. This hammock is designed for use by only one person at a time.
3. **DO NOT LEAVE CHILDREN UNATTENDED.** Children should also be helped on to and off the hammock.
4. **HAMMOCK MUST BE HUNG AND CHECKED UP BY AN ADULT.** In securing the hammock, the use of strong metal hooks, well secured onto posts, trees or roof structures is recommended. The hammock ends can then be directly attached to these hooks. Any post, tree, roof eave etc. should be judged to be strong enough to support the weight of intended users. If using ropes to connect the hammock ends to hooks or other structures, please ensure all knots are tied securely and will not come loose.
5. If securing to posts or trees, ensure hammock is secure so ropes will not slide downwards. Posts should be rounded so that ropes will not fray with use. **ROPES AND KNOTS SHOULD BE ALWAYS CHECKED BEFORE USE.**
6. The hammock should be inspected each time before use. Replace or re-do any suspect ropes or knots.
7. When not being used, keep in a dry place. Only roll and pack hammock when it is dry.



## ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

## TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

### General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### Warranty Conditions

#### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ**  
**SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR  
Headquarters: Dělnická 957, Vítkov, 749 01  
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264  
VAT ID: CZ26847264

Phone: +420 556 300 970  
E-mail: eshop@insportline.cz  
reklamace@insportline.cz  
servis@insportline.cz

Web: www.inSPORTline.cz

**SK**  
**inSPORTline s.r.o.**

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723  
VAT ID: SK2020177082

Phone: +421(0)326 526 701  
E-mail: objednavky@insportline.sk  
reklamacie@insportline.sk  
servis@insportline.sk

Web: www.inSPORTline.sk