



USER MANUAL – EN

IN 23669 Hunting bow inSPORTline Sacador 50lb



CONTENTS

- SAFETY INSTRUCTIONS..... 3
- ASSEMBLY 4
- POSTURE 6
 - STANCE..... 6
 - TORSO 6
 - HEAD 6
 - SHOULDER POSITION..... 6
 - ELBOW AND LOWER ARM POSITION..... 6
 - ANCHOR POINT 7
 - HOW TO NOCK ARROW 7
- ARROW 7
- MAINTENANCE 7
- PREPARATION..... 7
- ENVIRONMENT PROTECTION 8
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 8

SAFETY INSTRUCTIONS

WARNING: YOU NEED TO LEARN ABOUT LOCAL LAWS AND REGULATIONS BEFORE USING BOWS AND CROSSBOWS. USUALLY, YOU NEED TO BE 18 YEARS OLD AND NEED TO USE THE BOWS AND CROSSBOWS ON SAFE PLACE AND MUST BE SECURED AGAINST MISUSE.

- Read the manual carefully and keep it for future reference.
- Do not aim at other people or in direction of other people, even if you do not have an arrow nocked.
- Keep your arrow aimed towards the ground as you nock it.
- Take off jewelry or watches.
- Avoid dry-firing a bow (releasing the bowstring without a nocked arrow).
- It is recommended to wear an arm guard.
- Do not over draw.
- Use only for intended purposes, do not modify the bow.
- Always check the bow, string, and arrows. If you notice signs of damage or wear, stop using it immediately.
- Before shooting, check that your target range and its location is safe to shoot at, there are not people, animals or property that can be damaged.
- Target and target range must be able to stop the arrow.
- Do not shoot directly up.
- Always use recommended arrows.
- Others must stand behind the shooting person.
- Never walk-in front a shooting line, wait until it is safe to go.
- Never stand close person that is shooting a bow.
- Do not drink alcohol or take any drugs before or during shooting a bow.
- Do not shoot over ridge or obstacles.
- Suitable for recreational use.

ASSEMBLY

The limbs are marked upper and lower.



Attach limbs to the grip.





Attach string to the limbs.





POSTURE

STANCE

Place your feet approximately at shoulder width, place your weight evenly on both feet. Keep your legs relaxed, do not lock your knees. Slightly turn your torso and shoulders to your target.

TORSO

Keep your body straight. Learn proper posture and how to keep it regularly. Collar bone is parallel to the arrow. Hips should be straight, should not bend forward or backward or into or away from the bow. Your torso should not bend left or right, do not lean into or away from bow. If you are leaning too much, you may have a bow with long draw.

HEAD

Hold your head up straight with your chin level to the ground. Then turn your face to your target.

SHOULDER POSITION

Shoulder on your release arm should fall into position naturally when your elbow and lower arm are properly placed. Your bow arm's shoulder or front shoulder should be in natural position. Do not move the bow arm's shoulder up, down or into the torso. If you move your shoulder forward your bow has too long of a draw.

ELBOW AND LOWER ARM POSITION

Elbow on your release arm should point away from the target, forearm parallel to the ground. Elbow on your bow should point outward and slightly downward angle away from elbow. When correctly positioned the bow arm's elbow has a slight bend. Your thumb should be roughly at 45-degree angle.

ANCHOR POINT

With recurve bows users usually place bowstring under their chin or corner of their mouth.

With compound bows users usually anchor along or behind jawbone.

Every user has different anchor point. Most important is finding a natural anchor point and consistently holding a full draw each shot.

HOW TO NOCK ARROW

Place the arrow nock on the string without moving the bow too much. The arrow must hold lightly and can not be stuck on string.

ARROW

The optimal arrow length is different for each user. It is determined by the length of the archer's hand; it does not depend on the type of bow. It is important for everyone to know the length of their arrow and to use it as well. If the arrows are too short or too long, the bow will not be able to develop full draw. The length of the arrow (or draw) is given in inches (1 " = 2.54 cm). Extend your left hand and measure the distance from your chin to the second joint of your left thumb. This is the length of your arrows for sports and target archery.

MAINTENANCE

- Do not expose bow to extreme temperatures (high or low) and store in dry and shady place.
- Do not over draw.
- Use only recommended bowstring with the same length.
- Avoid dry-firing (releasing the bowstring without a nocked arrow)
- During shooting check that the bow is not damaged and that the bow is oriented at right side (stronger bow arm should be at the bottom).
- The bowstring must be dry when used.
- Store the bow with bowstring detached.

PREPARATION

Attach a bowstring with bow stringer:

1. Place the bowstring on one bow arm and second end leave freely.
2. Place the bow stringer over the bowstring and second end over the top of second bow arm.
3. Step on bow stringer and drag the bow up to the shoulders. Then attach second end of string.
4. Release the bow, remove the bow stringer and check that the bowstring is placed well.

Over the leg:

1. Place the bowstring on bottom arm.
2. Turn the bow so that handle is rested on back side of thigh and end of bottom arm of bow is rested on ankle.
3. Then bend the bow arms equally and place the second end of bowstring.
4. After that step out of the bow and check that the bowstring is placed well.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyards.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster

- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ

SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
 Headquarters: Dělnická 957, Vítkov, 749 01
 Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
 VAT ID: CZ26847264

Phone: +420 556 300 970
 E-mail: eshop@insportline.cz
 reklamace@insportline.cz
 servis@insportline.cz

Web: www.inSPORTline.cz

SK

inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
 VAT ID: SK2020177082

Phone: +421(0)326 526 701
 E-mail: objednavky@insportline.sk
 reklamacie@insportline.sk
 servis@insportline.sk

Web: www.inSPORTline.sk